

Step5/7-Programming system PG-2000

Installation note:

Load your license file using the link given in your personal license email.
The password for extraction can also be found in this email. Then copy this file into the folder of the installed PG-2000 software (demo version).
After restarting the software, your license is active.

<https://www.tpa-partner.de>

Menutree Website:

- + Products / docu / downloads
- + Software
- + Programming-software PG-2000 Step!
- + Basic packages AWL

QR-Code Website:



```

NOTIZEN: 1 USD, 0 MJUTHEILKPROGRAMMT
[EN] -Start=50,0
[EN] V7 0004,0
[EN] V 0
[EN] H 000,0
[EN] -Start=50,0
[EN] -Start=50,0
Name: SPB_PB 20
Name: SPB_PB 20
Name: SPB_PB 20
Name: SPB_PB 20

```

Please make sure to update your drivers before using our products.

Easy Web-Visualization




You need a web-visualization which is kept simple, with no additional Plugins like ActiveX, Flash(R) or Java(R) and is compatible with most general browser? Then you have found with S7-Visu the solution. Visualizations under Windows(R)/Linux on PC-based systems are just realizable as those for tablets or Phones with browser support. The simultaneous operation of multiple browsers at the same time is possible.

Worldwide access



No matter where you are, access to the EtherSens-device and its web-interface is available from everywhere.




With the S5-H1-PG-LAN you would be able to use the H1-path-selection over the S5-LAN++ and communicate with all PLCs in the H1-bus. You don't have to connect serial to the CP, you can do this easy over your network.

Remote-maintenance Siemens-S5-PLC




Remote-maintenance of a Siemens-S5-controller with S5-LAN++ on PD-port via secure VPN-tunnel of the TeleRouter

Data backup S7-PLC PN-port on SD-card



S7-PLC triggered DB-backup/-restore without additional PC via PN-port on SD card

Universally on machine and PLC



Remote access to all your systems, PLCs without great effort. Even triggering of actions by setting the integrated digital-outputs or reading in the digital and analog-inputs is possible via the Internet connection.

Regardless of whether you use your PC with the CONNECT-software or have connected a device from the CONNECT-family. Couplings via LTE also enable access to the LAN-interface on the system side. No special SIM-card is required for this.

A solution with little effort and everything within your "private" cloud.