Menutree Website: **QR-Code Website:**

+ Products / docu / downloads
  + Accessories
    + Antennas / Accessories
      + Sector antenna for ALF

Please make sure to update your drivers before using our products.

Universal communication at all interfaces

Wired or wireless communication (WIFI) via the same adapter with the respective control Devices from the BRIDGE-family always connect a wired-network with a wireless-network (WIFI) and a specific PLC-interface. This gives you access to the directly connected controller via WIFI (with S7 to the entire bus) as well as to the wired Ethernet. Of course also from wired Ethernet to WIFI and control/bus.
 Always connected to each other, all made possible by the devices of the BRIDGE-family.

Communication with S5-PLC via RS232, just how and with what?

Data-communication with S5-PLC from PC or other devices via RS232 (COM-port), which interface is required. Questions you don't have to worry about. With "S5 over RS232" you get the right interface-products for your interface of the PLC.

Which one you use then is up to you.

Remote maintenance / telecontrol of PLC-devices via LAN / internet

You have access to a on-site network and your PLC-device has no LAN-connection? No problem, plug the S7-LAN on the PLC-device and you will have immediate access to the PLC from afar.

With the S5-H1-PG-LAN you would be able to use the H1-path-selection over the S5-LAN++ and communicate with all PLCs in the H1-bus. You dont have to connect serial to the CP, you can do this easy over your network.

Data logging

Cyclic data logging or data logging on occasion is realisable. The log data will be transmitted e.g. once a day via e-mail.
Special data logger functions can be implemented on request and are not part of the basis functions.

EtherSens-cloud

By the EtherSens-cloud each EtherSens-device can exchange data, transfer data and forward to other devices. As if you use one device that records all necessary parameters centrally.

E-Mail notification

Do you monitor processes and upon reaching a predetermined upper/lower limit, you need a message? Then activate in the device the limit-value-monitoring and you get this message. Furthermore, the device also sends its state and you are always up to date.