

Menutree Website:


- + Products / docu / downloads
- + Accessories
 - + Connection cable / adapter
 - + TTY
 - + TD-OP-cable

QR-Code Website:




Please make sure to update your drivers before using our products.

Documentation of oxygen concentration




The integrated current output issues the actual concentration in the range of 0/4 - 20mA via free definable limits.

Data logger with FTP-interface




You need a data logger which tape-records the specified data of the PLC and you can collect the data via FTP on demand. No problem, TP-II with the option Datalogger is the solution for you.

Data backup S5-PLC on USB-stick via dig. IO



Via digital input triggered DB-backup/-restore without additional PC via PG-socket and Ethernet to USB-stick

Insensible communication with the S5-PLC



Safe communication with the S5-PLC in an environment of radiant-converters and motor-controls. Electrostatic-charging is also a KO-criterion for operation of interface-cable, a discharge and the interface-product is damaged or even defective.

PG-UNI-II is prepared for this, with its full-metal-cast-housing and ESD-proof components it offers the best protection against such influences. The shielding of the cable connected to the metal-housing is the solution. Of course, the cable can be extended to a TTY-distance of up to 300m, using of adapter for PG-UNI-cables is also possible.

To switch a MESSI-output via SMS




SMS-Versenden.
PASS=12345 DO1=1,16

```
PASS=12345 DO1=1,16
| | | | | 15 Sekunden Schaltzeit (0 bedeutet dauernd an)
| | | | | 1 = EIN, 2 = AUS (Bei AUS wird keine Schaltzeit beachtet)
| | | | | DO1 Schlüsselwort für Digitalausgang (DO1 bis DO8 möglich)
| | | | | Passwort aus dem Messpunkt Geräteeingang
| | | | | Schlüsselwort für Passwort
```


Switching an output via SMS is an integrated function of the MESSI. Herewith the switching operation will be secure and comprehensible from afar.

Recognize missing Profinet participants



Recognize cable breakage, contact problems and line faults.
Retransmissions and failures are logged and reported.
Early acting before total failure of the participant.

DB-Backup/Restore S7-PLC PN-port on USB-stick via dig. IO



Via digital input triggered DB-backup/-restore without additional PC via PN-port to USB-stick