Handling-Shortinstruction V1.0 for

CONNECT-HS-Router + CONNECT-Router industrial WiFi-router

Connectors:



Power connection :

Voltage:	$24~V~DC\pm20\%$
power consumption :	1,2W

Assignment of voltage plug :



Initial start-up:

- CONNECT-Router creates a WLAN network with an SSID "CONNECT WiFi" with active DHCP master (laptop is automatically assigned an IP address)
- Connect laptop to this WiFi network and open with browser webserver with IP: http://192.168.2.1
- or
- Connect the PC to the LAN port using a LAN cable
- PC must be in the 192.168.2.xxx subnet

Starting page:

	commissioning		
Before you can immediately rea On the page "co	start to use the device you will have to s dy for the communication. infiguration" you can change these as well	et up some basic settings. Afterward as some further settings at any time.	s your device will be
	basic configuration		
	In the first step you have to specify Specifying the name is optional.	how you want to use your devic	е.
	device name:		
	operation mode:	 Bridge Router 	
		n	ext

Basic configuration:

Assign a name to the device for identification

2 operating modes are possible with the CONNECT-Router :

- Bridge Multiple interfaces connected to a common network
- Router Separation between LAN and WAN (Internet) network

For operation mode Bridge:

LAN configuration		
In the last step you have to configure how your device should be connected with the local network.		
interfaces:	☑ LAN-A ☑ LAN-B ☑ WLAN	
─IP settings		
IP configuration:	DHCPmanually	
DHCP server:	☑ enable	
IP address:		
subnet mask:		
-WLAN settings		
search:	start search	
mode:	Access Point (AP) V	
SSID:	CONNECT WIFI	
security type:	open V	
channel:	auto channel V	
back	save	

LAN configuration: Determine the interfaces that should be bridged

IP settings:

 IP configuration: 	DHCP (parameters come from a DHCP master on the network)		
	Manual (IP addre	ss + subnet mask fields must contain valid values)	
- DHCP server:	Device is a DHC	P server on the selected interfaces	
- IP address:	IP address of the	IP address of the device	
- subnet mask:	Subnet mask of the device		
WLAN settings:			
- Search:	Searches for accessible WiFI networks and lists them. By clicking on an entry, the selected WiFi network is used for connection		
- Modus:	Access-Point (AP) [the CONNECT-Router opens its own WiFi]		
	Client [the CON	NECT-Router connects to an existing WiFi network]	
- SSID:	Name of the connected or created network		
- Sicherheitsstufe:	Open	(no encryption)	
	WEP	(either 5 or 13 ASCII/10 or 26 hexidecimal characters)	
	WPA	(8-64 ASCII characters)	
	WPA2	(8-64 ASCII characters)	
	WPA/WPA2	8-64 ASCII characters (Independent automatic selection whether WPA or WPA2)	
- Kanal:	Selection of the connection channel		

for operation mode Router:

	WAN configuration	
	Next you have to configure how your internet / WAN.	device should be connected with the
	WAN interface:	LAN-A 💌
	-IP settings	
	IP configuration:	O DHCP is manually
	IP address:	
	subnet mask:	
	dateway address:	
	back	next
WAN interface:	Set the WAN interface	from LAN-A, LAN-B oder WLAN
IP settings:		
- IP configuration:	DHCP (Parameters cor	ne from a DHCP master on the network)
	Manuell (fields IP Add valid values)	dress + Subnet Mask + Gateway Address must contain
- IP address:	IP address of the device	e
- subnet mask:	Subnet mask of the dev	vice
 gateway address: 	Gateway address of the	e device

LAN configuration:

Determine the interfaces that should be connected to the local network

LAN configuration		
In the last step you have to configure how your device should be connected with the local network.		
interfaces:	☑ LAN-B ☑ WLAN	
─IP settings		
IP configuration:	 DHCP manually 	
DHCP server:	enable	
IP address:		
subnet mask:		
-WLAN settings		
search:	start search	
mode:	Access Point (AP) v	
SSID:	CONNECT WIFI	
security type:	open v	
channel:	auto channel 🗸	
·		

back

save

IP settings:

DHCP (Parameters come from a DHCP master on the network)		
Manuell (fields IP address + subnet mask must contain valid values)		
Device is a DHCP server on the selected interfaces		
IP address of the device		
Subnet mask of the device		

WLAN settings:

Searches for accessible WiFI networks and lists them; by clicking on an entry,		
d for connection		
Access-Point (AP) [the CONNECT-Router opens its own WiFi]		
Client [the CONNECT-Router connects to an existing WiFi network]		
Name of the connected or created network		
Open	(no encryption)	
WEP	(either 5 or 13 ASCII/10 or 26 hexidecimal characters)	
WPA	(8-64 ASCII characters)	
WPA2	(8-64 ASCII characters)	
WPA/WPA2	8-64 ASCII characters (Independent automatic selection	
	whether WPA or WPA2)	
Selection of the connection channel		
	Searches for accessib d for connection Access-Point (AP) [tl Client [the CONNEC Name of the connecte Open WEP WPA WPA2 WPA2 WPA/WPA2 Selection of the connected	

By "Save" the selected configuration is adopted. The device is ready for use in the specified operating mode after a short waiting period (maximum 10s).

Situation	Operating mode	WLAN mode	Particularities
With a laptop around the S5/7 PLC + CONNECT-Router	Bridge	Access-Point	PLC via S5/7 LAN on LAN-A port, additional LAN participants on LAN-B port
Bring S5/7-PLC or LAN-participants into the existing WiFi network	Bridge	Client	PLC via S5/7-LAN / LAN- participant on LAN-A port, additional LAN-participant on LAN-B port
Create a separate subnet for connected devices	Router	Access-Point	LAN-A port to the company network, LAN-B port + WLAN to the machine network (Don't forget routes in the company network)
Extend LAN route Attention: 2 devices are required	Bridge	1. device Access- Point 2. device Client	One device as AP and the second as client

You need the following operating modes for the following situations :

After selecting the configuration, save it in the device and after a short initialization time (max. 10s) the devices are ready for operation.

You can find out more about the operating modes in the device manual on the CONNECT-Router product page.

(c) copyright 2000-2025 by TPA

Menutree Website:

+ Products / docu / downloads + Hardware + Router 3G / WLAN/WIFI + CONNECT-Router-devices + CONNECT-Router

<u>QR-Code Website:</u>





Please make sure to update your drivers before using our products.

PD-interface of the S5-PLC already occupied (OEM-device)



Your PD-interface of the S5-PLC is already occupied with a panel and you should accomplish program modifications without removing the panel? No problem, connect the Multiplexer one-time to the PLC and then connect the panel and also your PC to the Multiplexer. Now you can work parallel with the PLC without the need of affecting the operation of the panel.



You want to protect your system against unauthorized access and changes? No problem, with the S7-firewall you secure your system against unauthorized access and thus prevent deduction or alteration of your system and process data.

Automatical backup of your PLC



Guaranteeing security against production-downtimes through regular backups of S5- or S7-PLCs on your PC. S5/S7/H1-backup/restore-software saves all projected controls at a predetermined time. Whether every minute, hourly, daily, weekly or once a month, the PLC is completely read out and saved on the hard-disk/network-drive of the computer. If the backup-battery fails or the PLC is damaged, you can use this backup-file to restore the PLC.



You are looking for a device which can be operated even with DSL? No problem, just plug in your TELE-router to a DSL cable modem, enter the parameters relating to the access data into the device and you are connected to Internet.

Message dispatch from the PLC



Send directly from your PLC news, statuses, alarms as SMS or email.