

Menutree Website:


- + Products / docu / downloads
- + Software
 - + PLC-communication-driver
 - + S7-communication-driver
 - + S7-communication-driver over LAN
 - + S7-communication-driver LAN for WinCC

QR-Code Website:




Please make sure to update your drivers before using our products.

Remote maintenance of centralized PLC-devices




You have many PLC and you want to programm them central on one place? No problem, you have to connect them all to the KOR/MUX-Tele-Switch, connect it with the TP-II and after telephone connect you will be able with the PD-bus-selection of your Step5-software to go ONLINE. Of course the MOR/MUX-Tele-Switch is cascable, so you can connect up to 30 PLCs to the devices.

Energy-data acquisition




Do you also need the energy-consumption of your plant or need to determine the cos phi?
With the EtherSens Energy you can capture and record by using a Rogowski-coil or folding-core the required values.

Current S7 panels via WLAN to the S5 controller



Connect each S7-TCP-IP panel to your S5.
Now also available via WLAN for mobile workstations.
PARALLEL several panels and even simultaneous PG connections possible.
Include hard-to-reach places in your ERP system.

Remote-maintenance access independent of hardware



Why always take any additional hardware in the luggage for remote-access to your own systems and machines? Installing the Software-CONNECT on your PC you always have with it and access to your own CONNECT-cloud is always possible, no matter where you are.


Internet-access on the PC of course required.

Programming of S5-PLC's via LAN




You would like to respond to your S5-PLC via LAN, but not integrate an Ethernet-CP?
No problem, plug the S5-LAN++ on the PD-interface and access via LAN.

S7-1200/1500 to S5



Coupling S7-controller with PN-port at S5-controller with PD-port via network

Interface for Mitsubishi Melsec Fx- & A-series



Changes to Mitsubishi PLCs but no interface cable?

Use the SC09 cable to connect the PC to the Mitsubishi MELSEC FX & A series. Any PLC with an RS-422 interface can be connected. Including adapter cable for 8-pin DIN connection, firmly attached so that it can never be forgotten. One cable for both types, universal to the Mitsubishi PLC.