


Handling-Shortinstruction V1.0 for

SW-CONNECT


(Software tool for Windows replaces hardware device)




Requirements:

- at least Windows operating-system Win7, Win8, Win8.1, Win10 or Win11 (32- or 64-bit)
- Installation only possible as a user with admin-rights or as an administrator (users without admin-rights are not allowed to install Windows-drivers)

Installation:

- Download the tool to your PC via the SW-CONNECT product-page (see qr-code link on the following pages).
- Installation only as a user with admin-rights using Windows-Explorer with a right mouse click "Run as admin" on the "SW-CONNECT-Installer-Vxxx.exe" file or as an administrator (xxx stands for the respective version number)
- Follow the installation-script, after selecting the language and setting the installation target, the tool will be installed on the Windows-PC. The Windows-driver is automatically installed in the background.
- Start the tool by pressing the Windows key  and select the "SW-CONNECT" group in the alphabetically sorted list under "S". Open this and the actual tool „SW-CONNECT“ will be starten:



Initial configuration - CONNECT-Software... X


License: - select

Number: 1 ▲
▼

Name: WIN7SESSION32

Submit Abort

- Select the license file that you received by email and accept it, specify the number of the participant, analogous to the numbers of the CONNECT devices. A "device name" can also be specified. This name is then visible in the other devices like a hardware device.
- The basic settings are accepted by pressing the "Submit"-button. The tool is ready for the first connection setup.



CONNECT-Software X

Cloud Configuration Help

State

Connection:	waiting for connection
Error:	-
Local PC:	WIN7SESSION32 (#1)
Partner device:	-

Remote config

Device:	-
State:	-

Minimize

In the "Cloud" menu you can search for your devices and have them displayed. If necessary, disconnect, display the address of the partner-device and view and change the configuration of the partner-device with "Remote configuration".

In the "Configuration" menu, you can parameterize the connection setup, specify the IP addresses, specify the interfaces used or reset the tool to the status after installation.

You can find more about the software in the manual in the download area under:

(c) copyright 2000-2025 by TPA

Menutree Website:

- + Products / docu / downloads
- + Software
- + Remote maintenance
- + Network / internet
- + CONNECT-software

QR-Code Website:



Please make sure to update your drivers before using our products.

Without LAN-cable round of the PLC




You're right in the middle of your production line and should move around the machine and simultaneously observe / manage. No problem, you parameterize the S7-WLAN-Bridge, connect to the MPI-LAN and connect to an access-point or with the ad-hoc-network of your laptop and are ONLINE on the PLC.

Remote maintenance of your S5-PLC via LAN / Internet



You have access to a on-site network and your PLC has no LAN-connection? No problem, plug the S5-LAN on the PLC and you will have immediate access to the PLC from afar.

Relaycontacts 230VAC/16A directly over WIFI/LAN



Switch with the EtherSens Control with relay-output easily and directly over LAN or WIFI up to 230VAC/16A, switchable over web-browser, TCP/IP-protocol or PLC-controlled. At the same time you monitor the switching-states on the optional SD-card or on the FTP server.